

E700 tree of menus and functions

User interface

TOOL POS	
F1 ORIGIN	Position display (jogging).
F1 REF	Origin offsets.
F2 MACHIN	Display without offsets.
F3 IN USE	Display with factory offsets.
F2 GOTO	Display with all the offsets.
F3 TEACH	Go to a position.
F4 INC-	Set of an offset using teach-in (absolute value).
F5 INC+	Set of an offset using teach-in (incremental value).
F6 OTHER	Set of an offset using teach-in (incremental value).
F1 REF	Manual reference point search function.
F2 WH ON	Enable electric wheel.
F3 WH OFF	Disable electric wheel.
F5 IN ON	Enable the real time input state display.
F6 IN OFF	Disable the real time input state display.
EDIT	
F1 STEP	Breakpoint edition.
F2 SAVE	Save the current edited file.
F3 INS LN	Insert a line in editor.
F4 DEL LN	Delete a line in editor.
F5 HOME	Set the cursor to the beginning of the line.
F6 END	Set the cursor at the end of the line.
MEM	
F1 P.ON	Select the power-on programme.
F2 CYCLE	Select the cycle programme.
F3 SAVE	General save.
F4 ISOCHK	Check the cycle programme syntax (ISO language).
F5 UTIL	File utilities.
F1 NEW	Create a new file.
F2 DELETE	Delete a file.
F3 COPY	Copy a file to the SD card or to internal memory.
F4 { SDCARD	Select the SD card.
INTMEM	Select the internal memory.
F5 FILTER	Choose the file type to be displayed.
F6 OTHER	
F1 RENAME	Rename a file.
F2 DUPL	Duplicate a file.
F3 WPROT	Set a file to read only mode.
F4 TRANS	Transfer of all the file to the SD card (or to internal memory).
F5 CLEAN	Delete all the files from internal memory.
TRACE	
F1 WATCH	Real time value display.
F1 DEF	Default values (EMER, INITRDY, FLT[0] and RST[0]).
F2 LAST	Allow the display of the last four values.
F3 MODIFY	Modification of a value in real time.
F2 MDI	MDI mode.
F1 EXEC	Command execution.
F3 PREV	Command history, previous one.
F4 NEXT	Command history, next one.
F3 AUTOM	Trace in AUTOMAT.E7M programme.
F4 PROG	Trace in currently running programme.
F5 SIM -	Trace in previous simultaneous task.
F6 SIM +	Trace in next simultaneous task.

MENU

F1 USER	User parameters I.
F1 ...	First table.
F2 ...	Second table.
F3 ...	Third table.
F4 ...	Fourth table.
F5 MONIT	Monitor display. Real time value display. Only if MUSER.INI is not empty.
F6 OTHER	Next parameter set, if there is one. (User parameters II)
F1 ...	5 th table.
F2 ...	6 th table.
F3 ...	7 th table.
F4 ...	8 th table.
F5 ...	9 th table.
F2 ORIGIN	Origins (G54... types and G60 Dxx).
F1 INDEX	Select the origin number.
F1 EXIT ou	In G60, select D number or
F1 G54	Select G54.
F2 G55	Select G55.
F3 G56	Select G56.
F4 G57	Select G57.
F5 G58	Select G58.
F2 SUB	Subtract of a value.
F3 ADD	Addition of a value.
F4 RADIUS	Radius setting (G60 mode only).
F5 G54-8	Select G54 to G58 type mode.
F6 G60	Select G60 Dxx type mode.
F3 TOOL	
F2 SUB	Subtract of a value.
F3 ADD	Addition of a value.
F5 TOOL-	Decrement the tool number.
F6 TOOL+	Increment the tool number.
F4 COM	
F1 BUS	RS-485 bus.
F1 BS SRT	Bus Start. Start the connection as the master (only one master).
F1 YES	
F2 NO	
F2 BS SCN	Bus Scan. Search for who is on the bus (must be started).
F3 BS OFF	Bus OFF (disconnection).
F4 BS ON	Bus ON. Start the connection as a slave (all the others).
F6 INFOS	Informations on the state of the RS-485 bus.
F1 EXIT	Exit of <i>INFOS</i> display.
F2 SEND	Send to EmbOSView.
F2 USB	USB communication (optional COM board).
F3 ETHNET	Ethernet communication (optional COM board).
F1 XPING	Test of Ethernet communication (XPort AR ping. Restricted use, only in case of troubleshooting)
F2 UINFOS	User informations. 15 user variables stored in XPort AR RAM.
F1 FILE	Creation of a file in XPort AR Flash memory.
F1 XML	Internet style page file (\http\Userinfos.xml)
F2 CSV	Comma Separated Values (\http\Userinfos.csv)
then	
F1 WRITE	New file (overwrite the old one)
F2 APPEND	Append to the existing file
F3 SEND	Send a value through Ethernet (on the Web User Infos page)
F5 TYP -	Modify the data type (Long, Float or Bool)
F6 TYP +	Modify the data type (Long, Float or Bool)
F3 REMLOG	Remote Log to send message. Tag REMLOG at address http://a.b.c.d/Config (Uppercase letter 'C') and do RESET. Use RemLogProject.exe to receive on the PC side. The port number between E700 and PC must match. Choose a port greater or equal than 2000.
F1 OPEN	Open the line. Start with this!

	F2 CLOSE	Close the line when communication work is over.
	F3 SEND	Send the message introduced through the keyboard.
	F6 LIST	Display a message list which is stored in read only memory in cpu_comscr.c.
	F5 OSVIEW	Send the communication state on the embOSView terminal.
	F6 RESET	Reset of XPort AR. Same effect than power off of COM board. Expect a long time to initialize !
F5 DNC		DNC RS-232 communication. (Direct Numerical Control). The E700 can send or receive a file. In the case of DNC, the E700 is asking. The goal is to centralize the programmes.
	F1 EXEC	Execute the operation.
	F4 LIST	In the case of sending/reception of any file (only in this case), the INI files are prepared in a list to avoid full edition of filenames..
	F5 OP -	Select an operation in the following: Reception/sending of ISO/Uniprogram/any file. With the ISO and Uniprogram operation, the file extension is not mandatory.
	F6 OP +	
F6 RS232		Select the RS232 communication, used with E700File.exe.
F5 CONFIG		E700 configuration
	F1 GEN	General configuration (Max RPM 10 V, Inv. Tool Correct., remote control and axis number).
	F1 DEF	Default values (factory values)
	F1 YES	Confirmation
	F2 NO	
	F2 NAME	Name of the AXISSs
	F1 DEF	Default values (factory values)
	F1 YES	Confirmation
	F2 NO	
	F6 NO NAM	Pour «boucher les trous» (AXISSs inexistants)
F3 AXISS		Paramètres des AXISSs
	F1 DRIVER	Axis driver parameter
	F1 DEF	Default values (factory values)
	F1 YES	Confirmation
	F2 NO	
	F2 YASKAW	Yaskawa driver parameters. Typical configuration. No confirmation !
	F3 AXIS -	Select the axis to configure
	F4 AXIS +	Select the axis to configure
	F5	Change the value
	F6	Change the value
	F2 MOTION	Motion parameters
	F1 DEF	Default values (factory values)
	F1 YES	Confirmation
	F2 NO	
	F2 MODULO	To parametrize a circular axis (ex : MODULO 360 degrees)
	F3 AXIS -	Select the axis to configure
	F4 AXIS +	Select the axis to configure
	F5	Change the value
	F6	Change the value

F3 SPEED	Speed parameters
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F3 AXIS -	Select the axis to configure
F4 AXIS +	Select the axis to configure
F5	Change the value
F6	Change the value
F4 REF	Reference point parameters
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F2 YASKAW	Yaskawa driver parameters. Typical configuration. No confirmation !
F3 AXIS -	Select the axis to configure
F4 AXIS +	Select the axis to configure
F5	Change the value
F6	Change the value
F5 DIR	Direction parameters (moteur rotation direction) and limit switch configuration
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F3 AXIS -	Select the axis to configure
F4 AXIS +	Select the axis to configure
F5	Change the value
F6	Change the value
F6 WHEEL	Electrical wheel configuration
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F3 AXIS -	Select the axis to configure
F4 AXIS +	Select the axis to configure
F5	Change the value
F6	Change the value
F4 EXTERN	External button definition (START, STOP and PAUSE)
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F3 NO	Change the value
F4 YES	Change the value
F5 -	Change the value
F6 +	Change the value
F5 LNG	Language selection
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F5 -	Change the value
F6 +	Change the value
F6 OTHER	Other parameters
F1 PROG	Enable or disable Start and Cycle programmes
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	
F5 -	Change the value
F6 +	Change the value
F2 USER	Any user parameters
F1 DEF	Default values (factory values)
F1 YES	Confirmation
F2 NO	

F3 ACCESS Access management

- F1 TPOS** TOOL POS page access management
 - F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 NO** Change the value
 - F6 YES** Change the value
- F2 EDITOR** EDIT page access management
 - F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 NO** Change the value
 - F6 YES** Change the value
- F3 MEM** MEM page access management
 - F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 NO** Change the value
 - F6 YES** Change the value
- F4 TRACE** TRACE page access management
 - F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 NO** Change the value
 - F6 YES** Change the value
- F5 MENU** MENU page access management
 - F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 NO** Change the value
 - F6 YES** Change the value
- F6 SUPER** Password and security key access management
 - F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**

F4 SYSTEM Any system parameters

- F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**

F5 COM Communication parameters (DNC and RS-232)

- F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 -** Change the value
 - F6 +** Change the value

F6 OTHER Any parameters (ISO from SD card)

- F1 DEF** Default values (factory values)
 - F1 YES** Confirmation
 - F2 NO**
 - F5 NO** Change the value
 - F6 YES** Change the value

F6 OTHER	Diverse parameters
F1 LOGIN	To log in as Superuser
F1 LOGIN	Log in
F1 LOGOUT	Back to operator mode
F2 TESTS	Hardware tests
F1 ENCOD	Encoder test (electrical wheels)
F1 GRAPH	Select encoder to display
F3 RESET	Reset the starred encoder (*)
F2 ANALOG	Test of analog inputs and outputs (ADC/DAC)
F3 RESET	Reset of the min/max values
F4 INDEX	Select analog I/O number
F5 -	Change the value
F6 +	Change the value
F3 DIGITAL	Test of digital inputs and outputs
F3 OFF	Set the selected output to off state
F4 ON	Set the selected output to on state
F5 -	Change the value
F6 +	Change the value
F4 MEMORY	Memory test
F1 EXTRAM	External RAM test
F1 ADDRESS	Address line test
F2 STRESS	Stress test (fast accesses)
F2 FRAM	FRAM test
F1 ADDRESS	Address line test
F2 STRESS	Stress test (fast accesses)
F4 LOGRES	Reset the logged message
F5 FSAVE	FRAM binary content saving
F5 FLASH	Internal memory test
F1 RD WR	Execute read and write test
F2 FATCHK	FAT test
F3 SECCHK	Sector test (incorrect test)
F4 DUMP	Internal memory content saving
F6 STRESS	Stress test (fast accesses)
F6 SDCARD	SD card test
F1 RD WR	Execute read and write test
F6 STRESS	Stress test (fast accesses)
F5 OTHER	Other tests
F1 LED	LED test
F2 BEEP	Buzzer test
F4 SCREEN	Display pixel test
F5 KEY	Keyboard test
F6 DETECT	Hardware configuration detection
F6 PLOT	Graphical displaying of the motion
F3 LOGS	Stored messages
F1 SYSTEM	Operating system messages
F2 ERROR	Error messages
F3 UNIPRG	Uniprogram messages (SIM, line number)
F4 USER	User messages (Uniprogram LOG instruction)
F6 WRFILE	E700.LOG file generation
F4 CLOCK	Clock display and using time
F1 SETUP	System clock and date setting
F5 -	Change the value
F6 +	Change the value
F5 VER	Operating system version
F1 EXIT	Back to OTHER menu
F5 HELP	Manufacture data
F1 EXIT	Back to OTHER menu